

NET230N

Universal control panel for 230V operators
Operating instructions and warnings

Index

1	Warnings Summary	41	5	Advanced programming	75
2	Product Description	42	6	Messages shown on the Display	80
3	Technical data	42	7	Installation Test	80
4	Configurations	43	8	Product Disposal	80
4.1	Sliding gates	45			
4.2	Swing gates	51			
4.3	Overhead doors	57			
4.4	Barriers	63			
4.5	Sectional Doors (Not available)	69			

EN

1 WARNINGS SUMMARY

Read these warnings carefully; failure to respect the following warnings may cause risk situations.

⚠ WARNING Using this product under unusual conditions not foreseen by the manufacturer can create situations of danger, and for this reason all the conditions prescribed in these instructions must be respected.

⚠ WARNING DEA System reminds all users that the selection, positioning and installation of all materials and devices which make up the complete automation system, must comply with the European Directives 2006/42/CE (Machinery Directive), 2004/108/CE (electromagnetic compatibility), 2006/95/CE (low voltage electrical equipment). In order to ensure a suitable level of safety, besides complying with local regulations, it is advisable to comply also with the above mentioned Directives in all extra European countries.

⚠ WARNING Under no circumstances must the product be used in explosive atmospheres or surroundings that may prove corrosive and damage parts of the product.

⚠ WARNING To ensure an appropriate level of electrical safety always keep the 230V power supply cables apart (minimum 4mm in the open or 1 mm through insulation) from low voltage cables (motors power supply, controls, electric locks, aerial and auxiliary circuits power supply), and fasten the latter with appropriate clamps near the terminal boards.

⚠ WARNING All installation, maintenance, cleaning or repair operations on any part of the system must be performed exclusively by qualified personnel with the power supply disconnected working in strict compliance with the electrical standards and regulations in force in the nation of installation.

⚠ WARNING Using spare parts not indicated by **DEA** System and/or incorrect re-assembly can create risk to people, animals and property and also damage the product. For this reason, always use only the parts indicated by **DEA** System and scrupulously follow all assembly instructions.

⚠ WARNING Incorrect assessment of the impact forces can cause serious damage to people, animals or things. **DEA** System reminds the installer must verify that the impact forces, measured as indicated by the standard EN 12445, are actually below the limits set by the standard EN12453.

⚠ WARNING The compliance of the internal sensing obstacles device to requirements of EN12453 is guaranteed only if used in conjunction with motors fitted with encoders.

⚠ WARNING Any external security devices used for compliance with the limits of impact forces must be conform to standard EN12978.

 **WARNING** In compliance with EU Directive 2002/96/EC on waste electrical and electronic equipment (WEEE), this electrical product should not be treated as municipal mixed waste. Please dispose of the product and bring it to the collection for an appropriate local municipal recycling.

2 PRODUCT DESCRIPTION

NET230N is a universal control panel for **DEA** System 1 or 2 230V operators automations with or without encoder.

The main feature of this control board is its ease of configuration of inputs and outputs according to any needs thus ensuring adaptability to any type of automation. It is therefore easy to set up and exclude all unnecessary functions.

3 TECHNICAL DATA

NET230N

Power supply (V)	230 V ~ ±10% (50/60 Hz)
Fuse F2 (A)	5A
Fuse F1 (A)	160mA
Outputs 230V motors (maximum output current) (A)	2 x 600W
Auxiliaries power supply output	+24 V === max 200mA
"Warning" output	230 V ~ max 2x 40W
Electric lock output	max 1 art. 110 or 24V === output max 5W configurable
230V Flashing light output	230 V ~ max 40W
24V Flashing light output	24 V === max 100mA (per lampeggiante a led) art. LED24AI
Operating temperature range (°C)	-20÷50 °C
Receiver frequency	433,92 MHz
Transmitters type of coding	HCS fix-code - HCS rolling code - Dip-switch
Max remote controllers managed	100

CONFIGURATION OF THE CONTROL PANEL

The universal control unit NET230N can be used for the management of the following types (**LYPE**) of closures motorized by **DEA** System: swing and sliding gates, overhead doors and barriers.

In order to ensure maximum adaptability to each **LYPE** of closure, the control board provides an initial procedure, performed only at the first turn, for the optimal configuration of inputs, outputs and parameters (see diagram **A**). Once configured, the control panel will operate in the mode "dedicated" to the **LYPE** of selected closing. After performing the initial configuration it is sufficient to execute the standard programming for the installation on which it is operating.

All settings remain in memory even in the case of subsequent flare-ups (see diagram **B**).


If necessary the **LYPE** of configured closing can be later adjusted following diagram **C**.

FIRST CONTROL BOARD IGNITION

Configuration after the first ignition

- A** For the first control panel ignition, proceed as follows:

1. Apply power, the display shows in sequence the writing "**rES~**" and "**LYPE**" flashing;
2. Press the **OK** button and hold for 5 seconds until the display shows **d000** on the display;
3. Acting on the **[+]** and **[−]** keys, select the desired configuration depending on the type of installation (es. **d002**) and confirm by pressing the **OK** button;
At this point, the selection will be stored and reloaded each time in the future.
4. Follow signs, "**LYPE**", "**-00-**" followed by the symbol of closed gate "----".



Following ignitions

- B** If you have already saved a configuration, proceed as follows:

Apply power, the display shows in sequence the writing "**rES~**", "**LYPE**", "**-00-**" followed by the symbol of closed gate "----".

Modify the existing configuration


- C** If you have already saved a configuration and you want to change it, proceed as follows:

1. Hold down the **OK** button and give power, the display shows in sequence the writing "**rES~**" and "**LYPE**" flashing;
2. Press the **OK** button and hold for 5 seconds until the display shows **d000** (the value changes to match the previous configuration used) on the display;
3. Acting on the **[+]** and **[−]**, select the new desired configuration depending on the type of installation (es. **d002**) and confirm by pressing the **OK** button;

⚠ Stop the reconfiguration procedure prior to confirmation, involves loading the previous configuration by the control panel without any modification.

⚠ However, if the reconfiguration procedure is brought to an end, the new configuration will take the place of the previous one and will be reloaded each time in the future.

4. Follow signs, "**LYPE**", "**-00-**" followed by the symbol of closed gate "----".



4.1 SLIDING GATES CONFIGURATION

ELECTRICAL CONNECTIONS

Execute the wiring following the directions of table 1 and diagrams on page 46.

Table 1 "terminal board connections"

1-2	230 V ~ ±10% (50/60 Hz) power supply input		
3-4-5	 Operator 1 output 230 V ~ max 600W		
6-7-8	 Operator 2 output 230 V ~ max 600W (if present)		
9-10	 230 V ~ max 100 W output for open gate warning light (if P052=0) or courtesy light (if P052>1)		
11-12	 Flashing light output 230 V ~ max 40W		
13-14	 Electric-lock output max 1 art. 110 (if P062=0) or 24V --- output max 5W configurable (if P062≠0)		
15-16	 Led flashing light output max 1 art. LED24AI (24 V --- max 100 mA)		
17-18	 17 - N.C. 18 - Com Input 6 FCC 1. If it intervenes it stops M1 closing. If unused, short circuit.		
19-20	 19 - N.C. 20 - Com Input 5 FCA 1. If it intervenes it stops M1 opening. If unused, short circuit.		
21-22	 21 - N.C. 22 - Com Input 4 PHOTO 1. When enabled (see parameter P050 in the table), activation of PHOTO 1 provokes: an inversion of direction (during closing), the arrest of the movement (during opening), prevent the start (gate closed). If unused, short circuit.		
23-24	 23 - N.C. 24 - Com Input 3 SAFETY. If activated, it causes the inversion. See P055 and P056 on the parameters table. If unused, short circuit.		
25-26	 25 - N.O. 26 - Com Input 2 PED. If activated, it opens motor nr. 1 only.		
27-28	 27 - N.O. 28 - Com Input 1 START. In case of intervention it provokes: the operator opening or closing. It may operate as "inversion" mode (P49=0) or "step by step" mode (P49=1).		
29	 Aerial signal input		
30	 Ground aerial input		
31-32	 +24 V --- power supply output for auxiliary devices 200mA		

If the installation requires different commands and / or additional to the standard, you can configure each input to the required rate.

Refer to Chapter "Advanced Programming".


EN

SLIDING GATES



INTERNAL WIRING SET BY THE FACTORY

EXTERNAL WIRING SET BY THE INSTALLER

LUMYIA
max 40W

STANDARD PROGRAMMING

1 Power Supply

Give power supply, the display shows the following symbols "rES-", "TYPE", "-00-" and then "----".




* If the control panel has already been programmed and the power fails or is switched off - once power is returned and a START command is given, the position reset procedure is performed (see "rESP" in the table "WORKING STATUS MESSAGES" on page 80).

2 Visualisation of inputs and operations-counter status

1. Press the **OK** key for 15 seconds;

2. The display will show respectively:

Inputs status (check it's correct);




Total operations counter (* see P064):

i.g.: **c003** = 3x100* = 3000 operations performed

Maintenance operations-counter (* see P065):

i.g.: **c005** = 5*x500 = 2500 operations remaining before the maintenance intervention request (**c---** = manoeuvres-counter disabled)


3. Hold down the **OK** key to display a cyclic 3 options, or release the **OK** button to exit the parameter.



3 Selection type of operators

! IMPORTANT !


1. Scroll down the parameters with **[+]** and **[−]** keys until you visualise P028;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[−]** keys, set:
 - d005=LIVI 6RR;
 - d006=LIVI 9RR;
 - d007=GULLIVER / REV;
4. Confirm your choice by pressing the **OK** key (display returns again to P028).



4 Selection operating with or without encoder

! IMPORTANT !


1. Scroll down the parameters with **[+]** and **[−]** keys until you visualise P029;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[−]** keys, set:
 - d000=for operators with encoder;
 - d001=for operators without encoder;
4. Confirm your choice by pressing the **OK** key (display returns again to P029).



5 Selection of direction of motion


1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P063;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[-]** keys, set:
 - d000=motor in standard position (on the left of the gap);
 - d001=motor in inverted position (on the right of the gap);
4. Confirm your choice by pressing the **OK** key (display returns again to P063).

Warning: The parameter automatically reverses the motors output open/close and any limit switch input open/close.



6 Motor stroke learning

1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P003;
2. Access the parameter by pressing the **OK** key;
3. When "RPPr" flashes, continue pressing the **OK** key;
4. Release the **OK** key when "RPPr" stops flashing; the learning procedure starts;
5. Wait for the door searches and stops on the opening stop and then on the closing stop.
If you want to anticipate the stopping strokes in opening, you can manually intervene by giving an impulse to "Start" button (or pressing the "OK" on the control panel) simulating the stroke.
6. Once the procedure is ended, the display will show "----".




7 Transmitters learning

7.1 Transmitters coding selection


1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P027;
2. Confirm by pressing on the **OK** key;
3. Select the type of transmitter by scrolling **[+]** and **[-]** keys:
 - d000=fix rolling-code (suggested);
 - d001=complete rolling-code;
 - d002=dip-switch;
4. Confirm by pressing on the **OK** key (display shows again P027).

Warning: If you need to vary the type of encoding, and only if other remotes with different encoding are memorized, you need to erase memory (P004) **AFTER** you have set the new encoding.



7.2 Learning

1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P005;
2. Confirm by pressing on the **OK** key;
3. When the symbol “**LERr**” flashes, press on any key of the transmitter you want to memorize;
4. The display visualizes the number of the transmitter just memorized and then “**LERr**” flashing;
5. Memorize all necessary transmitters repeating this procedure from step 3;
6. Wait 10 seconds before quitting the memorization mode, display shows now “----”.




Warning: In the case of rolling code remotes, the receiver can be put into learning mode by pressing the hidden button on a remote control previously learned.

8 Adjustment of operating parameters

If you need to modify the operating parameters (force, speedness etc..):

1. Scroll down the parameters until you visualize the desire parameter (i.g. P032);
2. Confirm by pressing on the **OK** key;
3. By pressing on **[+]** and **[-]**, set up the desired value;
4. Confirm by pressing on the **OK** key (display shows the parameters previously selected).



For the complete list of the “Operating Parameters” See the table on page. 78.

9 Programming complete

WARNING At the end of the programming procedure, use the buttons **[+]** and **[-]** until the appearance of the symbol “----”, the operator is now ready again for new manoeuvres.

To perform any “Advanced Programming” operations (cancellation of the remotes, configuration inputs, etc ..), see on page 75.





4.2 SWING GATES CONFIGURATION

ELECTRICAL CONNECTIONS


Execute the wiring following the directions of table 1 and diagrams on page 52.

Table 1 "terminal board connections"

1-2	230 V ~ ±10% (50/60 Hz) power supply input	
3-4-5	Operator 1 output 230 V ~ max 600W	
6-7-8	Operator 2 output 230 V ~ max 600W (if present)	
9-10	230 V ~ max 100 W output for open gate warning light (if P052=0) or courtesy light (if P052>1)	
11-12	Flashing light output 230 V ~ max 40W	
13-14	Electric-lock output max 1 art. 110 (if P062=0) or 24V --- output max 5W configurable (if P062≠0)	
15-16	Led flashing light output max 1 art. LED24AI (24 V --- max 100 mA)	
17-18	<p>17 - N.C. Input 6 STOP. In case of intervention, it stops the movement of both motors during any operation. If unused, short circuit.</p> <p>18 - Com</p>	<p>If the installation requires different commands and / or additional to the standard, you can configure each input to the required rate.</p> <p>Refer to Chapter "Advanced Programming".</p>
19-20	<p>19 - N.C. Input 5 PHOTO 2. When enabled (see parameter P051 in the table), activation of PHOTO 2 provokes: an inversion of direction (during closing), the arrest of the movement (during opening), prevent the start (gate closed). If unused, short circuit.</p> <p>20 - Com</p>	
21-22	<p>21 - N.C. Input 4 PHOTO 1. When enabled (see parameter P050 in the table), activation of PHOTO 1 provokes: an inversion of direction (during closing), the arrest of the movement (during opening), prevent the start (gate closed). If unused, short circuit.</p> <p>22 - Com</p>	
23-24	<p>23 - N.C. Input 3 SAFETY. If activated, it causes the inversion. See P055 and P056 on the parameters table. If unused, short circuit.</p> <p>24 - Com</p>	
25-26	<p>25 - N.O. Input 2 PED. If activated, it opens motor nr. 1 only.</p> <p>26 - Com</p>	
27-28	<p>27 - N.O. Input 1 START. In case of intervention it provokes: the operator opening or closing. It may operate as "inversion" mode (P49=0) or "step by step" mode (P49=1).</p> <p>28 - Com</p>	
29	Aerial signal input	
30	Ground aerial input	
31-32	+24 V --- power supply output for auxiliary devices 200mA	

EN





STANDARD PROGRAMMING

1 Power Supply

Dare alimentazione, sul display compaiono in sequenza le scritte "rES-", "TYPE", "-0 !-" seguite dal simbolo di cancello chiuso "----"




* If the control panel has already been programmed and the power fails or is switched off - once power is returned and a START command is given, the position reset procedure is performed (see "rESP" in the table "WORKING STATUS MESSAGES" on page 80).

2 Visualisation of inputs and operations-counter status

1. Press the **OK** key for 15 seconds;

2. The display will show respectively:

Inputs status (check it's correct);




Total operations counter (* see P064):

i.g.: **3003** = $3 \times 100^*$ = 3000 operations performed

Maintenance operations-counter (* see P065):

i.g.: **c005** = 5×500 = 2500 operations remaining before the maintenance intervention request (**c---** = manoeuvres-counter disabled)


3. Hold down the **OK** key to display a cyclic 3 options, or release the **OK** button to exit the parameter.



3 Selection type of operators

! IMPORTANT !


1. Scroll down the parameters with **[+]** and **[−]** keys until you visualise P028;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[−]** keys, set:
 - d001=LOOK - MAC;
 - d002=GHOST;
 - d003=LIVI 500/502;
4. Confirm your choice by pressing the **OK** key (display returns again to P028).



4 Selection operating with or without encoder


! IMPORTANT !

1. Scroll down the parameters with **[+]** and **[−]** keys until you visualise P029;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[−]** keys, set:
 - d000=for operators with encoder;
 - d001=for operators without encoder;
4. Confirm your choice by pressing the **OK** key (display returns again to P029).




5 Selection 1 or 2 operators functioning

1. Scroll down the parameters with **+** and **-** keys until you visualise P030;
2. Access the parameter by pressing the **OK** key;
3. Acting on **+** and **-** keys, set:
 - d001=for a single motor operating;
 - d002=for 2 motors operating;
4. Confirm your choice by pressing the **OK** key (display returns again to P030).



6 Motor stroke learning


1. Scroll down the parameters with **+** and **-** keys until you visualise P003;
2. Access the parameter by pressing the **OK** key;
3. When "RPPR" flashes, continue pressing the **OK** key;
4. Release the **OK** key when "RPPR" stops flashing; the learning procedure starts;
5. Wait for the door (or doors in case of using 2 motors) searches and stops on the opening stop and then on the closing stop.
If you want to anticipate the stopping strokes in opening, you can manually intervene by giving an impulse to "Start" button (or pressing the "OK" on the control panel) simulating the stroke.
6. Once the procedure is ended, the display will show "----".



7 Transmitters learning

7.1 Transmitters coding selection


1. Scroll down the parameters with **+** and **-** keys until you visualise P027;
2. Confirm by pressing on the **OK** key;
3. Select the type of transmitter by scrolling **+** and **-** keys:
 - d000=fix rolling-code (suggested);
 - d001=complete rolling-code;
 - d002=dip-switch;
4. Confirm by pressing on the **OK** key (display shows again P027).



Warning: If you need to vary the type of encoding, and only if other remotes with different encoding are memorized, you need to erase memory (P004) **AFTER** you have set the new encoding.

7.2 Learning

1. Scroll down the parameters with **+** and **-** keys until you visualise P005;
2. Confirm by pressing on the **OK** key;
3. When the symbol "LEAr" flashes, press on any key of the transmitter you want to memorize;
4. The display visualizes the number of the transmitter just memorized and then "LEAr" flashing;
5. Memorize all necessary transmitters repeating this procedure from step 3;
6. Wait 10 seconds before quitting the memorization mode, display shows now "----".




Warning: In the case of rolling code remotes, the receiver can be put into learning mode by pressing the hidden button on a remote control previously learned.

8 Adjustment of operating parameters

If you need to modify the operating parameters (force, speedness etc.):

1. Scroll down the parameters until you visualize the desire parameter (i.g. P032);
2. Confirm by pressing on the **OK** key;
3. By pressing on **+** and **-**, set up the desired value;
4. Confirm by pressing on the **OK** key (display shows the parameters previously selected).



For the complete list of the "Operating Parameters" See the table on page. 78.

9 Programming complete

WARNING At the end of the programming procedure, use the buttons **+** and **-** until the appearance of the symbol “----”, the operator is now ready again for new manoeuvres.

To perform any "Advanced Programming" operations (cancellation of the remotes, configuration inputs, etc. ..), see on page 75.

EN





4.3 OVERHEAD DOORS CONFIGURATION

ELECTRICAL CONNECTIONS

Execute the wiring following the directions of table 1 and diagrams on page 58.

Table 1 "terminal board connections"

1-2	230 V ~ ±10% (50/60 Hz) power supply input	
3-4-5	Operator 1 output 230 V ~ max 600W	
6-7-8	Operator 2 output 230 V ~ max 600W (if present)	
9-10	230 V ~ max 100 W output for open gate warning light (if P052=0) or courtesy light (if P052>1)	
11-12	Flashing light output 230 V ~ max 40W	
13-14	Electric-lock output max 1 art. 110 (if P062=0) or 24V --- output max 5W configurable (if P062≠0)	
15-16	Led flashing light output max 1 art. LED24AI (24 V --- max 100 mA)	
17-18	17 - N.O. 18 - Com	Input 6. Unused.
19-20	19 - N.O. 20 - Com	Input 5. Unused.
21-22	21 - N.C. 22 - Com	Input 4 STOP. In case of intervention, it stops the movement of both motors during any operation. If unused, short circuit.
23-24	23 - N.C. 24 - Com	Input 3 SAFETY. If activated, it causes the inversion. See P055 and P056 on the parameters table. If unused, short circuit.
25-26	25 - N.C. 26 - Com	Input 2 PHOTO 1. When enabled (see parameter P050 in the table), activation of PHOTO 1 provokes: an inversion of direction (during closing), the arrest of the movement (during opening), prevent the start (gate closed). If unused, short circuit.
27-28	27 - N.O. 28 - Com	Input 1 START. In case of intervention it provokes: the operator opening or closing. It may operate as "inversion" mode (P49=0) or "step by step" mode (P49=1).
29	⋮	Aerial signal input
30	⋮	Ground aerial input
31-32	+24 V ---	power supply output for auxiliary devices 200mA


If the installation requires different commands and / or additional to the standard, you can configure each input to the required rate.

**Refer to Chapter
"Advanced Programming".**

EN

OVERHEAD DOORS





STANDARD PROGRAMMING

1 Power Supply

Give power supply, the display shows the following symbols "rES-", "TYPE", "-D2-" and then "----".




* If the control panel has already been programmed and the power fails or is switched off - once power is returned and a START command is given, the position reset procedure is performed (see "rESP" in the table "WORKING STATUS MESSAGES" on page 80).

2 Visualisation of inputs and operations-counter status

1. Press the **OK** key for 15 seconds;

2. The display will show respectively:

Inputs status (check it's correct);




Total operations counter (* see P064):

i.g.: **c003** = 3x100* = 3000 operations performed

Maintenance operations-counter (* see P065):

i.g.: **c005** = 5*x500 = 2500 operations remaining before the maintenance intervention request (**c---** = manoeuvres-counter disabled)


3. Hold down the **OK** key to display a cyclic 3 options, or release the **OK** button to exit the parameter.



! IMPORTANT !


3 Selection operating with or without encoder

1. Scroll down the parameters with **+** and **-** keys until you visualise P029;
2. Access the parameter by pressing the **OK** key;
3. Acting on **+** and **-** keys, set:
 - d000=for operators with encoder;
 - d001=for operators without encoder;
4. Confirm your choice by pressing the **OK** key (display returns again to P029).




4 Selection 1 or 2 operators functioning

1. Scroll down the parameters with **+** and **-** keys until you visualise P030;
2. Access the parameter by pressing the **OK** key;
3. Acting on **+** and **-** keys, set:
 - d001=for a single motor operating;
 - d002=for 2 motors operating;
4. Confirm your choice by pressing the **OK** key (display returns again to P030).



5 Motor stroke learning

1. Scroll down the parameters with **+** and **-** keys until you visualise P003;
 2. Access the parameter by pressing the **OK** key;
 3. When "APP_r" flashes, continue pressing the **OK** key;
 4. Release the **OK** key when "APP_r" stops flashing; the learning procedure starts;
 5. Wait for the door searches and stops on the opening stop and then on the closing stop.
- If you want to anticipate the stopping strokes in opening, you can manually intervene by giving an impulse to "Start" button (or pressing the "OK" on the control panel) simulating the stroke.
6. Once the procedure is ended, the display will show "----".




6 Transmitters learning

7.1 Transmitters coding selection

1. Scroll down the parameters with **+** and **-** keys until you visualise P027;
2. Confirm by pressing on the **OK** key;
3. Select the type of transmitter by scrolling **+** and **-** keys:
 - d000=fix rolling-code (suggested);
 - d001=complete rolling-code;
 - d002=dip-switch;
4. Confirm by pressing on the **OK** key (display shows again P027).


Warning: If you need to vary the type of encoding, and only if other remotes with different encoding are memorized, you need to erase memory (P004) **AFTER** you have set the new encoding.



7.2 Learning

1. Scroll down the parameters with **+** and **-** keys until you visualise P005;
2. Confirm by pressing on the **OK** key;
3. When the symbol "LEAR_r" flashes, press on any key of the transmitter you want to memorize;
4. The display visualizes the number of the transmitter just memorized and then "LEAR_r" flashing;
5. Memorize all necessary transmitters repeating this procedure from step 3;
6. Wait 10 seconds before quitting the memorization mode, display shows now "----".


Warning: In the case of rolling code remotes, the receiver can be put into learning mode by pressing the hidden button on a remote control previously learned.



7 Adjustment of operating parameters

If you need to modify the operating parameters (force, speedness etc.):

1. Scroll down the parameters until you visualize the desire parameter (i.g. P032);
2. Confirm by pressing on the **OK** key;
3. By pressing on **+** and **-**, set up the desired value;
4. Confirm by pressing on the **OK** key (display shows the parameters previously selected).



For the complete list of the “Operating Parameters” See the table on page. 78.

8 Programming complete

WARNING At the end of the programming procedure, use the buttons **+** and **-** until the appearance of the symbol “----”, the operator is now ready again for new manoeuvres.

To perform any “Advanced Programming” operations (cancellation of the remotes, configuration inputs, etc. ..), see on page 75.

EN

OVERHEAD DOORS





4.4 BARRIERS CONFIGURATION

ELECTRICAL CONNECTIONS

Execute the wiring following the directions of table 1 and diagrams on page 64.

Table 1 "terminal board connections"

1-2	230 V ~ ±10% (50/60 Hz) power supply input
3-4-5	Operator 1 output 230 V ~ max 600W
6-7-8	Operator 2 output 230 V ~ max 600W (if present)
9-10	230 V ~ max 100 W output for open gate warning light (if P052=0) or courtesy light (if P052>1)
11-12	Flashing light output 230 V ~ max 40W
13-14	Electric-lock output max 1 art. 110 (if P062=0) or 24V --- output max 5W configurable (if P062≠0)
15-16	Led flashing light output max 1 art. LED24AI (24 V --- max 100 mA)
17-18	17 - N.C. 18 - Com Input 6 STOP. In case of intervention, it stops the movement of both motors during any operation. If unused, short circuit.
19-20	19 - N.O. 20 - Com Input 5 CLOSE. If it intervenes, it causes the closing maneuver.
21-22	21 - N.O. 22 - Com Input 4 OPEN. If it intervenes it causes the opening maneuver.
23-24	23 - N.C. 24 - Com Input 3 SAFETY. If activated, it causes the inversion. See P055 and P056 on the parameters table. If unused, short circuit.
25-26	25 - N.C. 26 - Com Input 2 PHOTO 1. When enabled (see parameter P050 in the table), activation of PHOTO 1 provokes: an inversion of direction (during closing), the arrest of the movement (during opening), prevent the start (gate closed). If unused, short circuit.
27-28	27 - N.O. 28 - Com Input 1 START. In case of intervention it provokes: the operator opening or closing. It may operate as "inversion" mode (P49=0) or "step by step" mode (P49=1).
29	Y Aerial signal input
30	⊕ Ground aerial input
31-32	+24V AUX +24 V --- power supply output for auxiliary devices 200mA

If the installation requires different commands and / or additional to the standard you can configure each input to the required rate.

Refer to Chapter "Advanced Programming".


EN

BARRIERS



 INTERNAL WIRING SET BY THE FACTORY


 EXTERNAL WIRING SET BY THE INSTALLER



STANDARD PROGRAMMING

1 Power Supply

Give power supply, the display shows the following symbols "rES-", "TYPE", "-03-" and then "----".




* If the control panel has already been programmed and the power fails or is switched off - once power is returned and a START command is given, the position reset procedure is performed (see "rESP" in the table "WORKING STATUS MESSAGES" on page 80).

2 Visualisation of inputs and operations-counter status

1. Press the **OK** key for 15 seconds;

2. The display will show respectively:

Inputs status (check it's correct);




Total operations counter (* see P064):

i.g.: **c003** = 3x100* = 3000 operations performed

Maintenance operations-counter (* see P065):

i.g.: **c005** = 5*x500 = 2500 operations remaining before the maintenance intervention request (**c---** = manoeuvres-counter disabled)


3. Hold down the **OK** key to display a cyclic 3 options, or release the **OK** button to exit the parameter.



3 Selection type of operators

! IMPORTANT !


1. Scroll down the parameters with **[+]** and **[−]** keys until you visualise P028;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[−]** keys, set:
 - d003=PASS;
 - d004=STOP;
4. Confirm your choice by pressing the **OK** key (display returns again to P028).



4 Selection operating with or without encoder


! IMPORTANT !

1. Scroll down the parameters with **[+]** and **[−]** keys until you visualise P029;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[−]** keys, set:
 - d000=for operators with encoder;
 - d001=for operators without encoder;
4. Confirm your choice by pressing the **OK** key (display returns again to P029).



5 Selection 1 or 2 operators functioning


1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P030;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[-]** keys, set:
 - d001=for a single motor operating;
 - d002=for 2 motors operating;
4. Confirm your choice by pressing the **OK** key (display returns again to P030).



6 Selection of direction of motion


1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P063;
2. Access the parameter by pressing the **OK** key;
3. Acting on **[+]** and **[-]** keys, set:
 - d000=motor in standard position (on the right of the gap);
 - d001=motor in inverted position (on the left of the gap);
4. Confirm your choice by pressing the **OK** key (display returns again to P063).

Warning: The parameter automatically reverses the motors output open/close and any limit switch input open/close.



7 Motor stroke learning

1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P003;
2. Access the parameter by pressing the **OK** key;
3. When "RPPR" flashes, continue pressing the **OK** key;
4. Release the **OK** key when "RPPR" stops flashing; the learning procedure starts;
5. Wait for the boom (or booms if two opposite barriers) searches and stops on the opening stop and then on the closing stop. If you want to anticipate the stopping strokes in opening, you can manually intervene by giving an impulse to "Start" button (or pressing the "OK" on the control panel) simulating the stroke.
6. Once the procedure is ended, the display will show "----".




8 Transmitters learning

8.1 Transmitters coding selection


1. Scroll down the parameters with **[+]** and **[-]** keys until you visualise P027;
2. Confirm by pressing on the **OK** key;
3. Select the type of transmitter by scrolling **[+]** and **[-]** keys:
 - d000=fix rolling-code (suggested);
 - d001=complete rolling-code;
 - d002=dip-switch;
4. Confirm by pressing on the **OK** key (display shows again P027).

Warning: If you need to vary the type of encoding, and only if other remotes with different encoding are memorized, you need to erase memory (P004) **AFTER** you have set the new encoding.



8.2 Learning

1. Scroll down the parameters with **+** and **-** keys until you visualise P005;
2. Confirm by pressing on the **OK** key;
3. When the symbol "LERr" flashes, press on any key of the transmitter you want to memorize;
4. The display visualizes the number of the transmitter just memorized and then "LERr" flashing;
5. Memorize all necessary transmitters repeating this procedure from step 3;
6. Wait 10 seconds before quitting the memorization mode, display shows now "----".




Warning: In the case of rolling code remotes, the receiver can be put into learning mode by pressing the hidden button on a remote control previously learned.

9 Adjustment of operating parameters

If you need to modify the operating parameters, follow the procedure below.

Warning: In order to ensure an optimum operation, the parameters given in the table must be set as indicated for the type of barrier used.

1. Scroll down the parameters until you visualize the desire parameter (i.g. P032);
2. Confirm by pressing on the **OK** key;
3. By pressing on **+** and **-**, set up the desired value;
4. Confirm by pressing on the **OK** key (display shows the parameters previously selected).



For the complete list of the "Operating Parameters" See the table on page. 78.

Recommended values for standard "TYPE 03 - Barriers"

	BOOM	Running speed (P032 - P033)	Slowdown speed (P034)	Slowdown duration (P035 - P036)	Soft-start (P054)	Facilitation release (P057)	Stop margin (P058 - P059)
STOP	STOP_L (7,5 m)	75%	40%	20%	1	3	15
	STOP_L (6 m)	85%	30%	20%	1	3	15
	STOP_L (5 m)	90%	30%	30%	1	3	15
	STOP_L (4 m)	100%	25%	20%	0	2	15
	STOP_V (4 m)	100%	20%	40%	0	2	7
PASS	PASS_L (4 m)	100%	30%	30%	0	2	20
	PASS_V (3 m)	100%	25%	30%	0	1	5
	PASS_V (4 m)	85%	25%	30%	0	1	5

DA VERIFICARE

10 Programming complete

WARNING At the end of the programming procedure, use the buttons **+** and **-** until the appearance of the symbol "----", the operator is now ready again for new manoeuvres.

To perform any "Advanced Programming" operations (cancellation of the remotes, configuration inputs, etc ..), see on page 75.




5 ADVANCED PROGRAMMING

Here are some added programming procedures relating to remotes memory management and advanced configuration of the control inputs.

1 Deletion of memorized transmitters


1.1 Deletion of all transmitters

1. Scroll down the parameters until you visualize P004;
2. Confirm by pressing on the **OK** key;
3. When "EAnE" is flashing, press the **OK** key for a few seconds;
4. Release the **OK** key as soon as "EAnE" stops flashing;
5. All memorized transmitters have been deleted (display shows again P004).




1.2 How to search and delete a transmitter

1. Scroll down the parameters until you visualize P006;
2. Confirm by pressing on the **OK** key;
3. By pressing on **+** and **-** keys, select the transmitter you want to delete (eg. r003);
4. When "r003" flashes, confirm the deletion by pressing the **OK** key for a few seconds;
5. Release the **OK** key when appears "r---";
6. The selected transmitter is deleted (display shows again P006).



2 Resetting of default parameters

1. Scroll down the parameters until you visualize P007;
2. Confirm by pressing on the **OK** key;
3. When "DEF-" flashes, press the **OK** key;
4. Release the **OK** key as soon as "DEF-" stops flashing; Default parameters for the configuration currently in use are restored;
6. At the end of the operation display returns to P007.




Warning: After you restore the default parameters, you must program the control panel again and adjust all operating parameters, in particular, remember to properly set the configuration of parameters (P028 - P029 - P030 – operator configuration).

3 Locking-Unlocking access to programming

By using a "dip-switch" remote (regardless of the type of remotes already memorized) it's possible to lock-unlock access to the programming of the control panel to avoid tampering. The remote setting is the locking-unlocking code verified by the control board.


3.1 Locking access to programming

1. Scroll through the parameters with the buttons **+** and **-** until the display shows P008;
2. Access the parameter by pressing the button **OK**;
3. The display shows alternately the writing Pr0G/FrEE to indicate that the control board is waiting for the transmission of the block code;
4. Within 10 seconds press CH1 on the "TX Master", the display shows Pr0G/bLOC before returning to the list of parameters;
5. Access to programming is locked.



3.2 Unlocking access to programming

1. Scroll through the parameters with the buttons **[+]** and **[-]** until the display shows P008;
2. Access the parameter by pressing the button **OK**;
3. The display shows alternately the writing **PrOG/bLOC** to indicate that the control board is waiting for the transmission of the unlocking code;
4. Within 10 sec. press the CH1 of the "TX Master", the display shows **PrOG/FREE** before returning to the list of parameters;
5. Access to programming is unlocked.




3.3 Unlocking access to programming and global reset

WARNING! This procedure involves the loss of all stored settings.

The procedure allows the unlocking of the control panel without having to know its unlocking code.

Following this release, you must program the control panel again and adjust all operating parameters, **in particular, remember to properly set the configuration of parameters (P028 - P029 - P030 - operator configuration)**. You will also need to repeat the measurement of impact forces to ensure the installation compliance to standards.


1. Scroll through the parameters with the buttons **[+]** and **[-]** until the display shows P008;
2. Access the parameter by pressing the button **OK**;
3. The display shows alternately the writing **PrOG/bLOC**;
4. Press the button **OK**, the display shows the flashing writing **FREE**;
5. Press the button again and hold for 5 seconds (releasing it before, the procedure is terminated): The display shows the fixed writing **FREE** followed by **dEF-**, before returning to the list of parameters;
6. Access to programming is unlocked.



4 Inputs configuration

Where the installation requires different commands and / or additional to the standard ones described by plan, you can configure each input for the operation desired (eg START, PHOTOS, STOP, etc ...).

1. Scroll down the parameters with the **[+]** and **[-]** to see that corresponding to the desired one:
 - P017=for INPUT 1;
 - P018=for INPUT 2;
 - P019=for INPUT 3;
 - P020=for INPUT 4;
 - P021=for INPUT 5;
 - P022=for INPUT 6;
2. Confirm by pressing on the **OK** key to get access to the parameter (eg. P018);
3. Scroll down with the **[+]** and **[-]** keys to set the value corresponding to the desired operation (refer to table "Input Configuration parameters" on page 77);
4. Confirm by pressing on the **OK** key (display shows again P018).
5. Execute the new connection to the input just reconfigured.



5 Programming complete

WARNING At the end of the programming procedure, use the buttons **[+]** and **[-]** until the appearance of the symbol "----", the operator is now ready again for new manoeuvres.

PAR.	PROCEDURE	SETTABLE VALUES									
		PROGRAMMING PROCEDURES									
PQ01	Positioning of operator 1										
PQ02	Positioning of operator 2										
PQ03	Memorization of the motors' stroke										
PQ04	Deletion of transmitters										
PQ05	Transmitters memorizing										
PQ06	Search and deletion of a transmitter										
PQ07	Loading of standard parameters: the list is up dated with factory settings										
PQ08	Lock access to programming										
PQ09	Unused parameter										
PQ10	Unused parameter										
PQ11	Unused parameter										
PQ12	Unused parameter										
PQ13	Unused parameter										
PQ14	Unused parameter										
PQ15	Unused parameter										

PAR.	PARAMETER DESCRIPTION	SETTABLE VALUES (for different standards of installation)									
		dEF1 sliding gate	dEF1 swing gate	dEF2 overhead door	dEF3 barriera	dEF4 sectional doors	DEFAULT VALUES				
PQ16	INPUT_3 selectionning input type						dEF1	dEF1	dEF1	dEF1	dEF1
		• 000: INS type= free contact									
		• 001: INS type= constant resistance 8K2									
PQ17	INPUT_1 operating selection						IN1	DI (START)	DI (START)	DI (START)	DI (START)
PQ18	INPUT_2 operating selection						IN2	DI (PEDESTRIAN)	DI (PEDESTRIAN)	DI (PEDESTRIAN)	DI (PEDESTRIAN)
PQ19	INPUT_3 operating selection						IN3	DI (SAFETY)	DI (SAFETY)	DI (SAFETY)	DI (SAFETY)
PQ20	INPUT_4 operating selection						IN4	DI (PHOTO 1)	DI (PHOTO 1)	DI (PHOTO 1)	DI (PHOTO 1)
PQ21	INPUT_5 operating selection						IN5	DI (FC1)	DI (FC1)	DI (FC1)	DI (FC1)
PQ22	INPUT_6 operating selection						IN6	DI (STOP)	DI (STOP)	DI (STOP)	DI (STOP)
PQ23	Allocation of CHANNEL 1 of remotes						CH1	DI (START)	DI (START)	DI (START)	DI (START)
PQ24	Allocation of CHANNEL 2 of remotes						CH2	DI (NONE)	DI (NONE)	DI (NONE)	DI (NONE)
PQ25	Allocation of CHANNEL 3 of remotes						CH3	DI (NONE)	DI (NONE)	DI (NONE)	DI (NONE)
PQ26	Allocation of CHANNEL 4 of remotes						CH4	DI (NONE)	DI (NONE)	DI (NONE)	DI (NONE)
	Selection of type of remotes							DI	DI	DI	DI
PQ27											

INPUTS CONFIGURATION PARAMETERS

Unused Parameter

OPERATORS CONFIGURATION PARAMETERS		OPERATING PARAMETERS			
		dEF0 sliding gate	dEF1 swing gate	dEF2 overhead door	dEF3 barriers
P028	Selection type of operators	<ul style="list-style-type: none"> • 001: IOK / NAC • 002: GHOST • 003: LVI 500/502 / 902 / LATO / PASS • 004: STOP • 005: LVI 6RR • 006: LVI 9RR • 007: GULLIVER / REV 	005	001	003
P029	Selected work with or without encoders.				004
	WARNING: P029 must be set correctly before performing the procedure for programming				
P030	Selectioning operators number	<ul style="list-style-type: none"> • 001: one operator • 002: two operators 	001	002	001
P031	Unused parameter				
P032	Operators speed adjustment during the stroke while opening	15%tot.....100%tot	003	001	003
P033	Operators speed adjustment during the stroke while closing	15%tot.....100%tot	003	001	003
P034	Operators speed adjustment during slow-down while opening and closing	15%tot.....100%tot	049	050	030
P035	Slow down duration adjustment while opening	5%tot.....80%tot	025	020	030
P036	Slow down duration adjustment while closing	5%tot.....80%tot	025	020	030
P037	Operator 1 force adjustment while opening (if = 100% obstacle detection deactivated)	15%tot.....100%tot	050	050	099
P038	Operator n.1 force adjustment while closing (if = 100% obstacle detection deactivated)	15%tot.....100%tot	050	050	099
P039	Operator n.2 force adjustment while opening (if = 100% obstacle detection deactivated)	15%tot.....100%tot	050	/	099
P040	Operator n.2 force adjustment while closing (if = 100% obstacle detection deactivated)	15%tot.....100%tot	050	/	099
P041	Automatic closing times adjustment (if = 0 automatic closing deactivated)	0sec.....255sec	000	000	000
P042	Pedestrian automatic closing time adjustment (se = 0 pedestrian automatic closing deactivated)	0sec.....255sec	000	000	000
P043	Pedestrian stroke duration adjustment	5%tot.....100%tot	030	035	030
P044	Pre-flashing time adjustment	0sec.....10sec	000	000	000
P045	Adjustment of phase displacement time while opening	0sec.....30sec	/	001	/
P046	Adjustment of phase displacement time while closing	0sec.....30sec	/	003	/
P047	Collectivity function: if it is activated it deactivates both opening and closing inputs for the whole duration of automatic opening and closing	<ul style="list-style-type: none"> • 000: "collectivity function" deactivated • 001: "collectivity function" activated 	000	000	000
P048	Ram blow function: it pushes the motors closed for one second before each opening movement, so as to ease the electric-lock release			000	000
P049	"Reversal" mode selection (during the manoeuvre a command impulse reverses the movement) or "step by step" (during the manoeuvre a command impulse stops the movement). A next impulse restart the operator to the opposite direction.			001	000
P050	PHOTO input functioning: if=0 photocells are enabled while closing and at gate closed if=1 photocells are always enabled; if=2 photocells are enabled while closing only. When enabled, its activation provokes: the inversion (while closing), the stop (while opening) and prevent the starting (when gate is closed). If=3-4-5, the operation is the same as the values 0-1-2 but with "close immediately" enabled: in any case, during the opening and/or the pause time, removal of a possible obstacle causes the gate automatically closes after a fixed delay of 3 sec.	<ul style="list-style-type: none"> • 000: photocells enabled while closing and at gate closed • 001: photocells always enabled • 002: photocells enabled only while closing • 003: as 000 but with "close immediately" enabled • 004: as 001 but with "close immediately" enabled • 005: As 002 but with "close immediately" enabled 	002	002	002
P051	PHOTO 2			001	002
P052	Operation mode selection of the warning light output: If = 0 "warning light" (output always ON when the gate is open, OFF after a closing operation), If > 1 "courtesy light" (output ON during each movement, OFF when the motor stops, after the setting delay). Operation mode selection of the warning light output: • 000: "fix warning light" • >01: "courtesy light" off delay (1sec.....25sec)			000	001

Unused Parameter

		dEF4 Sectional doors	dEF3 barriers	dEF2 overhead door	dEF1 swing gate	dEF0 sliding gate	
P053	Searches for end of stroke while opening too: when activated, operators stop only at their arrival at the end of stroke, also while opening.				/		
P054	"soft start" function: motors accelerate gradually until they reach the set speed, avoiding sudden departures				000: Stop when opening on a memorized point 001: Stop when opening on the end of stroke		
P055	Adjust the inversion on obstacle period (detected by internal anti-crushing sensor or by the safety input when activated); If = 0 it makes a complete inversion; If > 0 indicates the duration (in seconds) of the run, after inversion resulting from detection of an obstacle during the opening.				000: "soft start" deactivated 001: "soft start" activated		
P056	Adjust the inversion on obstacle period (detected by internal anti-crushing sensor or by the safety input when activated); If = 0 it makes a complete inversion; If > 0 indicates the duration (in seconds) of the run, after inversion resulting from detection of an obstacle during the closing.				000: inversione completa su ostacolo 001: durata dell'inversione su ostacolo (1sec.....10sec)		
P057	Facilitation manual release: If ≠ 0, after detecting the locking stop, the engine reverses for a brief time to release the pressure on it, and thus facilitate the manual release. The set value shows the length of the inversion. If ≠ 0 function disabled				000: complete reversal on obstacle 001: duration of reversal on obstacle (1sec.....10sec)		
P058	Margin adjustment of the opening stroke: adjusts the duration of the last stretch of the race during which any obstacle is interpreted as a stroke, stopping the operator without executing the inversion. The value set indicates the number of revolutions of the rotor.				000: facilitating release disabled 001: facilitation activated with release time equal to: (1x25ms.....20x25ms) (only Type 0)		
P059	Margin adjustment of the closing stroke: adjust the duration of the last stretch of the race during which any obstacle is interpreted as a stroke, stopping the operator without executing the inversion. The value set indicates the number of revolutions of the rotor.				000: 1.....255	/	
P060	Operators force adjustment at stroke arrival - If = 0, setting off (the force value on the stroke is calculated automatically) - If ≠ 0, indicates the value (expressed in % of the max value) of the force exerted on the stroke.				000: 0%off.....100%off	025	
P061	Unused parameter					/	
P062	Electric-lock operating: if = 0 electric-lock art. 110, if= 1 24V output commanded by ELOCK_IN input in impulsive mode, if=2 24V output commanded by ELOCK_IN input in step-by-step mode, If= 3 24V output for piloting the electrobrake on REV sliding operator, If>3 24V output commanded by ELOCK_IN input in temporized mode (the set value indicates the delay of turning off expressed in sec).				000: "Electric-lock art. 110 output 001: "24V d.c. max 5W Impulsive output 002: "24V d.c. max 5W Step-by-Step Output 003: REV electrobrake output >003: "24V d.c. max 5W Temporized output (4sec.....255sec)		
P063	Run direction inversion: If=1 automatically reverses the outputs open/close of the operators and any opening/closing limit switches inputs, avoiding having to manual change the wiring when installing the operator in an inverted position.				000: "Standard installation" 001: "Inverted installation"	000	
P064	Multiplication Operations-counter: Multiply the number of operations after which the total operations-counter will be updated. To view the values, refer to the section "Visualisation of inputs and operations-counter status". i.g.: If P064 = 050, operations number = 50x500 = 25000 operations				000: "x100 001: "x1000 002: "x10000 003: "x100000	000	
P065	Maintenance Operations-counter: if = 0 reset the counter and disables the intervention request , if> 0 indicates the number of operations (x 500) to be made before the control panel executes a 4 second additional pre-flash to indicate the need of maintenance. i.g.: P064 = 050, operations number = 50x500 = 25000 operations				000: "Request Maintenance disabled 001: "Number of operations (x 500) for required maintenance (1.....255)	000	
P066	Warning: Before you set a new value of the counter-maneuvres maintenance, the same must be reset by setting P065= 0 and only later P065 = "new value".				000: "intermittent flashing light output 001: "fixed flashing light output	001	
P067	Unused parameter						
P068	Unused parameter						
P069	Unused parameter						
P070	Unused parameter						

Unused Parameter

OPERATING PARAMETERS

6 MESSAGES SHOWN ON THE DISPLAY

WORKING STATUS MESSAGES	
Mess.	Description
----	Gate is closed
JL	Gate is opened
OPEN	Opening under way
CLOS	Closing under way
STEP	While in step-by-step mode, the control board awaits further instructions after a start command
BLOC	Stop command received
rESP	Reset current position: The control unit has just been turned on after a power failure, or the gate has exceeded the maximum number (50) of inversions allowed without ever getting to the closing stroke, or the maximum number (3) of consecutive operations allowed of the anti-crushing device. Once the control unit has been reset and open command given the gate will start moving at slow speed, until it reaches end of travel. At this stage any start pulses are ignored.

ERROR MESSAGES		
Mess.	Description	Possible solutions
ErrP	Error position: The reset position procedure is not successful. The control panel is awaiting commands.	- Make sure there are no specific frictions and / or obstacles during the run; - Give a start pulse to initiate a position reset procedure; - Verify that the operation is completed successfully, manually helping the run, if necessary; - Adjust power and speed settings if necessary.
Err3	External photocells and/or safety devices are activated or out of order.	- Make sure that all safety devices and/or photocells installed are working properly.
Err4	Possible failure to the control board power circuit.	- Disconnect and connect power supply. Give a start impulse, if this error appears again, replace the control board.
Err5	Time-out operators run: The engine/s exceeded the maximum operating time (5min) without ever stopping.	- Give a start pulse to start the position reset procedure; - Ensure that this operation is successful.
Err6	Time-out obstacle detection: With anti-crushing sensor disabled, was still detected the presence of an obstacle that prevents movement of the leaf for a period of 10 seconds more.	- Make sure there are no specific frictions and / or obstacles during the run; - Give a start pulse to initiate a position reset procedure; - Verify that the operation is completed successfully.
Err7	Operators mouvement not detected.	- Make sure that operators and encoders connections are well done. - Check the setting of parameter P029 (Motor selection with or without encoder) and make sure it is correct. - If this error appears again, replace the control panel.

7 INSTALLATION TEST

The testing operation is essential in order to verify the correct installation of the system. **DEA** System wants to summarize the proper testing of all the automation in 4 easy steps:

- Make sure that you comply strictly as described in paragraph 2 "WARNINGS SUMMARY";
- Test the opening and closing making sure that the movement of the leaf match as expected. We suggest in this regard to perform various tests to assess the smoothness of the gate and defects in assembly or adjustment;
- Ensure that all safety devices connected work properly;
- Perform the measurement of impact forces in accordance with the standard 12445 to find the setting that ensures compliance with the limits set by the standard EN12453.

8 PRODUCT DISPOSAL

 **WARNING** In compliance with EU Directive 2002/96/EC on waste electrical and electronic equipment (WEEE), this electrical product should not be treated as municipal mixed waste. Please dispose of the product and bring it to the collection for an appropriate local municipal recycling.

Questo manuale è stato realizzato utilizzando carta ecologica riciclata certificata Ecolabel per contribuire alla salvaguardia dell'ambiente.

This manual was printed using recycled paper certified Ecolabel to help save the environment.

Ce manuel a été réalisé en utilisant du papier recyclé certifié Ecolabel afin de respecter l'environnement.

El manual ha sido fabricado utilizando papel reciclado certificado Ecolabel para preservar el medio ambiente.

Este manual foi impresso com papel reciclado certificado Ecolabel para ajudar a preservar o meio ambiente.

W celu wsparcia ochrony środowiska, niniejszą instrukcję zrealizowaliśmy wykorzystując papier ekologiczny pochodzący z recyklingu i posiadający certyfikat Ecolabel.



DEA SYSTEM S.p.A. - Via Della Tecnica, 6 - ITALY - 36013 PIOVENE ROCCHETTE (VI)
tel. +39 0445 550789 - fax +39 0445 550265 - Internet <http://www.deasystem.com> - e-mail: deasystem@deasystem.com